FireShield Operating Instructions

To Silence Audible / Visual Alarms

Warning: Alarm signals should not be silenced until all occupants have been evacuated ...

- 1. Press the Signal Silence Drill button.
- 2. Determine the cause of condition.

To Reset The Fire Alarm Panel

- 1. Press the Reset button.
- 2. If system does not Reset, contact your Installer for service.

To Silence the Fire Alarm Panel buzzer

- 1. Press the Panel Silence button on the panel.
- 2. Determine the type of condition that caused the buzzer to sound: [alarm, trouble, supervisory or monitor]
- 3. Determine the cause of condition.
- 4. System will automatically reset upon correction of trouble condition.

To Activate a Fire Drill

1. Press the Signal Silence & Drill button.

To Turn Off Fire Drill

1. Press the Signal Silence Drill button or Reset button.

For Service, Contact:

NAC Divisions 2014 Lincoln Way East Chambersburg, Pa 17202 (717) 261-0123 service@nacdivisions.com