

---

## Instructions for the Level 2 operator (emergency mode access)

### Tasks that require you to log on as a Level 2 operator

#### What is it you want to do

#### This is how you do it

**Log onto the panel as a Level 2 operator**

Turn the Enable Controls key 1/4 of a turn clockwise.

— or —

1. Press Menu.
2. Choose Login then enter the password required for Level 2 access.

**Reset the panel**

Press System Reset.

**Turn off alarm signaling circuits when the panel is in alarm (Alarm Silence)**

Press Alarm Silence.

**Turn on alarm signaling circuits when the panel is not in alarm (Drill)**

Press Drill then Enter.

**Get a list of all events processed on a panel**

1. Press Menu.
2. Choose Reports > History.
3. Enter the panel number.
4. Choose Display to view the list on the CPU/Display unit.

— or —

Choose Printer to print the list.

**Change the password required for Level 1 access**

1. Press Menu.
2. Choose Program > Edit Password > Level 1.
3. Enter the new password.

**Switch automatic detectors to their alternate sensitivity settings**

1. Press Menu.
2. Choose Activate > Alt Sens.

**Switch automatic detectors to their primary sensitivity settings**

1. Press Menu.
2. Choose Restore > Prm Sens.

**Tasks that require you to log on as a Level 2 operator**

<b>What is it you want to do</b>	<b>This is how you do it</b>
<b>Distribute event records according to their alternate message routing</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Activate &gt; Alt Msg Route.</li></ol>
<b>Distribute event records according to their primary message routing</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Restore &gt; Prm Msg Route.</li></ol>
<b>Disable a Zone</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Disable &gt; Zone.</li><li>3. Select a Zone from the pick list then press Enter.</li></ol>
<b>Enable a Zone</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Enable &gt; Zone.</li><li>3. Select a Zone from the pick list then press Enter.</li></ol>
<b>Disable a device</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Disable &gt; Device.</li><li>3. Enter the device address, where: PP is the panel number (01) CC is the card number DDD is the circuit or device number</li></ol>
<b>Enable a device</b>	<ol style="list-style-type: none"><li>1. Press Menu.</li><li>2. Choose Enable &gt; Device.</li><li>3. Enter the device address, where: PP is the panel number (01) CC is the card number DDD is the circuit or device number</li></ol>