
Vigilant VS Operating Instructions

To Silence Audible / Visual Alarms

Warning: Alarm signals should not be silenced until all occupants have been evacuated...

1. Press the Signal Silence button.
2. Determine the cause of condition.

To Reset The Fire Alarm Panel

1. Press the Reset button.
2. If system does not Reset, contact your Installer for service.

To Silence the Fire Alarm Panel buzzer

1. Press the Panel Silence button on the panel.
2. Determine the type of condition that caused the buzzer to sound: [alarm, trouble, supervisory or monitor]
3. Determine the cause of condition.
4. System will automatically reset upon correction of trouble condition.

To Activate a Fire Drill

1. Press the Drill button.

To Turn Off Fire Drill

1. Press the Drill button or Reset button.

For Service, Contact:

NAC Divisions
2014 Lincoln Way East
Chambersburg, Pa 17202
(717) 261-0123
service@nacdivisions.com