
Instructions for the Level 2 operator (emergency mode access)

Tasks that require you to log on as a Level 2 operator

What is it you want to do	This is how you do it
Log onto the panel as a Level 2 operator	Turn the Enable Controls key 1/4 of a turn clockwise. — or — <ol style="list-style-type: none">1. Press Menu.2. Choose Login then enter the password required for Level 2 access.
Reset the panel	Press System Reset.
Turn off alarm signaling circuits when the panel is in alarm (Alarm Silence)	Press Alarm Silence.
Turn on alarm signaling circuits when the panel is not in alarm (Drill)	Press Drill then Enter.
Get a list of all events processed on a panel	<ol style="list-style-type: none">1. Press Menu.2. Choose Reports > History.3. Enter the panel number.4. Choose Display to view the list on the CPU/Display unit. — or — Choose Printer to print the list.
Change the password required for Level 1 access	<ol style="list-style-type: none">1. Press Menu.2. Choose Program > Edit Password > Level 1.3. Enter the new password.
Distribute event records according to their alternate message routing	<ol style="list-style-type: none">1. Press Menu.2. Choose Activate > Alt Msg Route.
Distribute event records according to their primary message routing	<ol style="list-style-type: none">1. Press Menu.2. Choose Restore > Prm Msg Route.

Tasks that require you to log on as a Level 2 operator

What is it you want to do	This is how you do it
Disable a Zone	<ol style="list-style-type: none">1. Press Menu.2. Choose Disable > Zone.3. Select a Zone from the pick list then press Enter.
Enable a Zone	<ol style="list-style-type: none">1. Press Menu.2. Choose Enable > Zone.3. Select a Zone from the pick list then press Enter.
Disable a device	<ol style="list-style-type: none">1. Press Menu.2. Choose Disable > Device.3. Enter the device address, where: PP is the panel number (01) CC is the card number DDD is the circuit or device number
Enable a device	<ol style="list-style-type: none">1. Press Menu.2. Choose Enable > Device.3. Enter the device address, where: PP is the panel number (01) CC is the card number DDD is the circuit or device number