

	Location: _____
Installed By: _____ _____ Per NFPA Standard: <input type="checkbox"/> 72, Ch 3 - Local <input type="checkbox"/> 72, Ch 4 - Auxiliary <input type="checkbox"/> 72, Ch 4 - Remote Sta. <input type="checkbox"/> 72, Ch 4 - Proprietary <input type="checkbox"/> 72, Ch 4 - Central Sta. Dated: _____	<div style="background-color: black; color: white; text-align: center; padding: 5px;">Fire Alarm Control Panel Operating Instructions</div> <p>Normal Condition: The Power LED (green) is on. All other LEDs are off.</p> <p>Alarm Condition: The Alarm LED (red) turns on, the display shows the alarm location and zone, and the internal buzzer pulses.</p> <p>To view additional alarms: Press the ALARM review switch (down arrow). To silence audible devices: Press the Alarm Silence switch to turn the audible signals off. To resound audible devices: Press the Alarm Silence switch a second time. To reset the system: After investigating the alarm condition, press the Reset switch.</p> <p>Note: New alarms will resound the audible signals.</p> <p>Supervisory Condition: The Supervisory LED (yellow) turns on, the display shows the supervisory condition, location, and zone, and the internal buzzer pulses.</p>
For Service Contact: NAC DIVISIONS 2014 Lincoln Way East Chambersburg, PA 17202 Ph: (717)261-0123 Fx: (717)261-0782 service@nacdivisions.com	<p>To view additional supervisory messages: Press the SUPVR review switch (down arrow). To silence buzzer: Press Local Silence switch. Investigate the cause. To clear system: Press the Reset switch.</p> <p>Trouble Condition: The system Trouble LED (yellow) turns on, the display shows the trouble location and zone, and the internal buzzer pulses.</p> <p>To view additional trouble messages: Press the TRBLE review switch (down arrow). To silence the buzzer: Press the Local Silence switch. Investigate the cause of the trouble To clear the system: The system will clear itself automatically upon correction of trouble condition.</p> <p>Monitor Condition: The Monitor LED (yellow) turns on, the display shows monitor conditions, and the internal buzzer pulses during a non-fire alarm condition.</p>
Power Supply: Primary _____ Location _____ Fuses _____ Secondary _____ Type _____ Specs. _____	<p>To view additional monitor conditions: Press the MONTR review switch (down arrow). To clear system: The system will clear itself automatically upon restoration of monitor condition.</p> <p>Fire Drill: Notify the fire department of the test.</p> <p>To drill and sound all audible devices: Press the Drill switch. All audible/visible signals will operate. To end the drill: Press the Drill switch a second time, or press Alarm Silence.</p> <p>Frame these instructions and mount them next to control panel.</p>